Warranty Card

Remarks:

- 1. This guarantee card should be kept by the user, no replacement if lost.
- 2. Most new products carry a two-year manufacturer's warranty from the date of purchase. Further details, pls read http://www.retevis.com/after-sale/
- 3. The user can get warranty and after-sales service as below:
- Contact the seller where you buy.
- Products Repaired by Our Local Repair Center
- 4. For warranty service, you will need to provide a receipt proof of purchase from the actual seller for verification

Exclusions from Warranty Coverage:

- 1. To any product damaged by accident.
- 2. In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs.
- 3. If the serial number has been altered, defaced, or removed.

Hong Kong Svbony Technology Co.,Ltd.

Add: Unit B, 5th Floor, Gallo Commercial Building, 114-118 Lockhart Road, Wanchai, Hong Kong

EU Importer: Germany Retevis Technology GmbH

Add: Uetzenacker 29,38176 Wendeburg


Web: www.svbony.com
E-mail: info@svbony.com

Facebook: facebook.com/svbony



Made in China

SVBONY



SV166

OPERATION AND USE

- Adjustment of visibility: Loose the visibility adjustment ring, turn the eyepieces until the crosshair can be clearly seen.

 Then turn the visibility. Adjustment ring and lock the eyepieces.
- Mounting and adjusting: Connect the aiming stand with the rifle first, then turn the riflescope so as to the transverse Line of the crosshair be in horizontal direction. Then adjust the position of the riflescope for comfortable aiming. At last, wring all the regular screws.
- Shooting correction: Aim at an object 100 Yards away, have a trial fire, then take a measurement of the horizontal and vertical distance between the point of Impact ane the point of aiming. After turning down the protection covers, turn the upper hand wheel and right side hand wheel as instructed in table 2. Fire and adjust again and again until the point of impact and the point of aiming are coincided.

TABLE 2


POSITION OF THE POINT OF IMPACT		UPPER LEFT	PPER LEFT LOWER LEFT		LOWER RIGHT
ROTATIONAL DIRECTION	UPPER HAND WHEEL	clockwise	Counter clockwise	clockwise	Counter clockwise
	RIGHTSIDE HAND WHEEL	Counter clockwise	Counter clockwise	clockwise	clockwise

NOTE: When the hand - wheel is turned for each click value It means the point of Impact is moved 7mm correspondingly in the distance of 100 Yards

HOW TO CARE YOUR RIFLESCOPE

- The riflescope doesn't engage the acids and the alkalis etc.
- Never wipe directly the dirt and dust on the surface of the lenses with your hands. Use soft silk or the lens cloth of a little alcohol.
- When it's damaged carelessly, please contact our maintenance departments' or our factory.

This riflescope can be coupled with airgun, hunting rifle, semi - automatic rifle etc. Because of crosshair being used Instead of the traditional front sight and notch base, the aiming speed, accuracy and percentage of hits are greatly increased. Its outer covering is made of high - strength aluminium alloy and undergoes specially anti corrosive treatment. The surface of all the optical spare parts are plated with anti - reflection coatings. Therefore, it's anti - vibration, fog - proof and shock - resistant etc.



- ① Objectives
- ③ Right side hand wheel
- ⑤ Eyepieces

- 2 Upper hand wheel
- ④ Visibility adjustment ring

HOW TO CARE YOUR RIFLESCOPE

TABLE 1

IAGNIFICA- TION	FIELD OF VIEW(100YDS)	TUBE DIAMETER	OBJECTIVE DIA	EXIT PUPIL (mm)	EYE DIS	LENGTH
3-9X40AO	12.56°-37.71°	Ф25.4mm	Ф40mm	4.25-12.4	84-101mm	316mm

NOTE: Scope Range 300 meters only & Manufactured in away which does not allow development

Warranty Card

Product model:	Date of purchase:
Serial Number:	
Seller:	Contact number:
Jsername:	Contact number:
Address:	
7in codo:	